


RJB -CONTROL



EASY, FAST, SAFE
FULL CONTROL ON YOUR FINGERTIPS



**ABER
MOVE**

RJB INDUSTRIES
SPREADING OUR QUALITY AROUND THE WORLD

Specifications



- Weight: 350 g / 600 g
- Inputs:
 - 7-30 VDC
 - 24 VAC
 - No Polarity
- IP69K
- Minimum 1A
- Dimensions: 120 x 80 x 50 mm

EASY TO INSTALL



1 Step
Install the
RJB I-Control System
(consult electric scheme)



2 Step
Download the RJB I-Control APP
(IOS & Android)



3 Step
Connect your Smartphone
to your RJB I-Control System

Bets way to control your Yacht Gangways or Passerelles from your smartphone.





Bets way to control your Yacht Garage Door from your smartphone.

SAFE FOR USERS

- RJB I-Control provides a SN Card with Serial Number and Master Code.
- At the first contact with each RJB I-Control, ADMINISTRATORS are required to create their own Admin Code and General User Code.
- If required to have a specific code per each OUTPUT, the ADMINISTRATORS are able to create UC Codes per OUTPUT.
- Admin Code and User Codes can be changed at anytime.
- To change any Code it is necessary the Admin Code.
- The ADMINISTRATOR can provide Master Code and General User Code (or UC Codes) to the users.
- To be in accordance with the European Norms and Regulations of Privacy Access, in case of loss of the Admin Code there is no way to recover the RJB I-Control access.

RJB I-CONTROL

SERIAL NUMBER

██████████

MASTER CODE

██████████

(To Share ONLY with Users)

Create Admin and User / UC codes, write them below and keep this card in a safe place.

Admin Code

General User Code

(Don't Share this Code)

(To Share ONLY with Users)

Specific Codes

(Optional)


UC1 _____ UC3 _____

UC2 _____ UC4 _____

www.rjbi-control.com

This card is personal and non-transferable. DON'T LOSE THIS CARD

RJB *i-CONTROL*



Portugal | Europe

✉ info@rjbi-control.com

🖥 www.rjbi-control.com